




## Instructions

## Trend® 4 Panel (FXXF) Installation










Interlock block must align with the mohair slot. Position block to feed mohair through the slot on the block.

Fix Interlock Block with 6G x 13mm screw through the centre hole of the block






5 Before installing the Sliding Panel, Adjust the rollers both sides to lower the panel




To adjust rolle




Locate adjustment screw through elongated hole


Rotate clockwise to raise the panel, counterclockwise to lower the panel





6 Position Sliding Panel so that it is in the open position. Lift Sliding Panel into the inside channel (1) of the Head Frame. Repeat step with the other sliding panel









Please note that drawings are not to scale