

# Awning Window - Features & Benefits

# **FRAME**

 Robust 102mm semi commercial aluminium window frame - ideal for larger window applications.

# **SASH**

- 62mm wide window sash section.
- Sash protected from the weather by a continuous hinge hood.
- Head, sill and jamb rails all have flat infill for clean lines.

# **SILL**

 Modern sill provides a clean appearance from the inside and the outside. Awning window can be coupled to large fixed lite windows.

### **GLAZING & ENERGY EFFICIENCY**

- All Trend® Windows and Doors comply with Australian Standards AS1288.
- Glazing options from 4mm single glazed to 24mm insulated glazed units (IGUs).
- Energy efficiency options available to help reduce home energy consumption.
- All glazing options are Window Energy Rating Scheme (WERS) rated - providing a wide range of energy efficient solutions.


### **ACOUSTICS**


- Acoustic solutions available for improved noise reduction
- High R<sub>W</sub> ratings available .

### **WIND & WATER RATINGS**

- All Trend® Windows and Doors comply with Australian Standards AS2047 and are designed to meet and surpass 700Pa wind velocity rating and 150Pa water penetration rating.
- Pascal deflection rates up to 2200Pa.
- Awning window rated at an air infiltration of 0.16L/s m<sup>2</sup> (below the the National Construction Code (NCC) for Air conditioned spaces of 1.00L/s m<sup>2</sup>) perfect for both air conditioned and non-air conditioned spaces.









# Awning Window - Features & Benefits

# **SECURITY**

- Awning windows come standard with key lockable scissor arm winder.
- 100mm child-safe window opening restrictor is available.
- Optional Prowler Proof security screens available.

### **BUSHFIRE**

- Xtreme® Bushfire Protection option available.
- Xtreme® options have been tested by CSIRO to meet BAL-40 - compliant to AS1530.8.1 within Australian Standards AS3959-2009.



# **HARDWARE**

- High performance key lock scissor action winder mechanism.
- Infinity Satin Chrome hardware comes standard on awning windows.
- Optional colours available:
  - Pearl White
  - Stone Beige
  - Anodic Natural Matt
  - Gloss Black
- For frames higher than 1499mm and/or wider than 1201mm, side cam lock is standard.
- Window locks can be keyed alike to other Quantum® products for ease of use.

### **OPTIONS**

- Glazing options also available in bar layout styles:
  - Colonial
  - Federation
  - Ovolo glazing bar style\*
- Wide range of powder coated colours.
- Easy to fit and remove flyscreens available.
- Customised WERS ratings.
- Variety of sizes and custom made options available (including bay window styles).
- Variety of configuration options available.

\*Ovolo only available in single glazing..


# **DELIVERY**


 Protective wrapping for delivery to site comes standard for all Quantum® products.

Note: Care should be taken when placing awning window near pedestrian access.











# Quantum® Awning Window Installation



Building In Detail | Brick Veneer - 240mm wall




# **INSTALLING FRAME CORRECTLY**


- Fit flashing to window surround (refer to drawing below).
- Measure the frame opening to ensure that there is sufficient room for the product and additional packing.

### Stud Opening:

Height = Frame Size + 60mm Width = Frame Size + 60mm


- Secure aluminum windows by nailing through reveal into studwork - fixing at 450mm maximum centres.
- Sill bricks should be at least 10mm clear of window frame to allow settlement in brick veneer construction.
- Header beam should be at least 12mm clear of window frame.
- Do not permit weight of eaves or arch bars to bear on any window or door frame. (Windows and doors are not load bearing.)
- To ensure the satisfactory long term performance of window, install sill support (refer to drawings below).







Building In Detail | Double Brick - 280mm wall




# **INSTALLING FRAME CORRECTLY**


- Fit flashing to window surround (refer to drawing below).
- Measure the frame opening to ensure that there is sufficient room for the product and additional packing.

# **Brick Opening:**

Height = Frame Size + 3mm Width = Frame Size + 3mm


- Secure aluminum windows by using building lug fixing at 450mm maximum centres.
- Sill bricks should be at least 10mm clear of window frame to allow settlement in brick veneer construction.
- Do not permit weight of eaves or arch bars to bear on any window or door frame. (Windows and doors are not load bearing.)







Building In Detail | Double Brick - 280mm wall | Prepared Opening




# **INSTALLING FRAME CORRECTLY**


- Fit flashing to window surround (refer to drawing below).
- Measure the frame opening to ensure that there is sufficient room for the product and additional packing.

### **Brick Opening:**

Height = Frame Size + 3mm Width = Frame Size + 3mm

- Secure aluminum windows by using building lug fixing at 450mm maximum centres.
- Sill bricks should be at least 10mm clear of window frame to allow settlement in brick veneer construction.
- Do not permit weight of eaves or arch bars to bear on any window or door frame. (Windows and doors are not load bearing.)







Building In Detail | Cladding on Studs




# **INSTALLING FRAME CORRECTLY**


- Fit flashing to window surround (refer to drawing below).
- Measure the frame opening to ensure that there is sufficient room for the product and additional packing.

### Stud Opening:

Height = Frame Size + 60mm Width = Frame Size + 60mm

- Secure aluminum windows by nailing through reveal into studwork fixing at 450mm maximum centres.
- Header beam should be at least 12mm clear of window frame.
- Do not permit weight of eaves or arch bars to bear on any window or door frame. (Windows and doors are not load bearing.)







Building In Detail | Blockwork




# **INSTALLING FRAME CORRECTLY**


 Measure the frame opening to ensure that there is sufficient room for the product and additional packing.

### **Blockwork Opening:**

Height = Frame Size + 80mm Width = Frame Size + 20mm

- Fit subframe to opening and seal fixings.
- Seal ends of subsill with angle.
- Fit window to subframe (screw or pop-rivet).
- Do not permit weight of eaves or arch bars to bear on any window or door frame. (Windows and doors are not load bearing.)







Building In Detail | Hebel Power Panel




# **INSTALLING FRAME CORRECTLY**


- Fit flashing to window surround (refer to drawing below).
- Measure the frame opening to ensure that there is sufficient room for the product and additional packing.

### Stud Opening:

Height = Frame Size + 60mm Width = Frame Size + 60mm

- Secure aluminum windows by nailing through reveal into studwork - fixing at 450mm maximum centres.
- Caulk between render and frame.
- Header beam should be at least 12mm clear of window frame.
- Do not permit weight of eaves or arch bars to bear on any window or door frame. (Windows and doors are not load bearing.)
- To ensure the satisfactory long term performance of windows, install sill support (refer to drawings below).














# Quantum® Awning Window Cross Sectional Views




# Single Lite
















Two Lite | Transom | Elevation





# Two Lite | Transom | Plan












# Two Lite | Transom | Double Glazed








# Two Lite | Transom | Double Glazed















Ovolo

