









On Site Fitting instruction for 3 panel Sliding Door FXF



Kit contains

Items	Description	Quantity
	Frame Factory fitted sill tread and fix panel adaptor	1
	Panels A-Fixed panel B-Sliding panel C-Fixed panel	1 1 1
	Flyscreen Adaptor and blocks	3
	Top fix block & 3 Lite Fixed Block	3
	63X8# Pan head Stainless Steel	1
	12X8# Pan head Stainless Steel	4
	20X6# Csk head Stainless Steel	6
	12X6# Pan head Stainless Steel	5

Installations



1- Make sure the frame installed onsite is square and level.

2- Insert Top fix blocks into top of the Interlock on Fix panel (A)





3- Place the Fix panel(A) onto the frame.
- Slip the top panel into the middle channel of the Head frame.

- Position the bottom panel inside the fix channel on the sill (Bottom frame).
Check the bottom interlock to make sure the fix panel fitting in.




4 - On the inside, place screws (20x6) along the Jamb, approx. 500mm from top and bottom, between the mohair to fix panel to the Jamb .

5-On top of the interlock, lift the Top fix block to touch the Head frame.
Use screw (12X8) to secure it to frame.




-On top of the interlock, use screw (63X8) to secure Top fix block to the panel.





6- Place the Fix panel (C) onto the frame.

-Place 3 Lite fixed blocks onto the sill .Locate Fixed panel (C) sits on it.




7 - On the outside, place screws (20x6) along the Jamb, approx. 500mm from top and bottom, between the mohair to fix panel to the Jamb .

8- Place the blocks on both end of the flyscreen adaptor.
Using 12X6# screws screw along the flyscreen adaptor to the fixed panel on the outside .



9-Use 12X6# to fix the bottom to frame.

10- Place the sliding panel into frame on the inside.
- If required, Adjust the rollers from either end of sliding panel with phillips screwdriver.



11- Fitting the door lock handle as in Lock fitting instruction